


Address setting:

model	Function show
Auto	When 10 at NO, 5.6.7.8.for speed setting,for OFF slow,for ON fast, 9 for strobe setting,forON have strobe effect,for OFF do not have effect 1—4 for effect choose ,all have 16 effect,1—4 for ON, play effect
sound	1—8.10 for OFF,sound,9 for strobe setting, forON have strobe effect,for OFF do not have effect
donkey engine	1 for ON,2—10 for OFF donkey engine model
DMX	10 for OFF,1—9 for address setting ,2 channal

Note

This product in the factory works good, packing integrity. All users should strictly abide by the above statement warnings and operating instructions, any damage caused by misuse, the company does not guarantee. Ignore manuals caused fault and problem also is not responsible for the dealer.

LED seven heads magic light



User Guide

UNPACKING INSTRUCTION

Unpacking:

Thanks you for purchasing this product.Please read user guide for safety and operations information before using the product.Keep this manual for future reference. Please check the attachments listed on the page after opening carton box. In the event of carton damage of attachments missing in transit,please contact your dealer or our after sales service department.

Attachment: 1. Light:1pcs 2. User Guide:1pcs 3. Power cable:1pcs

NOTICE

- 2, Do not turn on and off the unit frequently.
- 3, Makes sure the power supply connects ground before using.
- 4, This unit is applicable for only indoor use and must be avoided water,moisture and shade damage.Working temperature should be 18~30℃.
- 5, Do not use it successively over 4 hours,otherwise it will shorten its lifetime.
- 6, Use cleaning tissue to remove dust on the external lenses periodically to optimize light output.
- 7, Do not remove or break the warranty label,otherwise it void warranty.
- 8, Always replace with the exact same type fuse,replacement with anything other than the specified fuse can cause fire or electric shock and damage your unit,and will overstep our manufacture's warranty.

TECHNICAL SPECIFICATION

- 1, Voltage: AC110V,50HZ/60HZ,
- 2, Power:50W
- 3.Working Modes:Sound Active,Auto,Master-Slave

Channal setting:

channel	Channel value	function
Ch1	0~4	Not effect
	5~25	15 effect choose
	252~255	Sound effect
CH2	0~255	speed (fast—show)
CH3	0~4	Not effect
	5~255	strobe(fast—show)
CH4.CH6.CH7.CH8. CH9.CH10.CH11 (CH12<49 CH4<4)	0~35	Not
	36~49	Spread effect(CH2.CH33 have effcet)
	50~255	Still effect (CH3 have effect)
CH12	0~49	Not effect
	50~91	Red
	92~133	Green
	134~175	Blue
	176~218	All light