


LED PAR 36



User Guide

Page 1

UNPACKING INSTRUCTION

Unpacking:

Thanks you for purchasing this product. Please read user guide for safety and operations information before using the product. Keep this manual for future reference. Please check the attachments listed on the page after opening carton box. In the event of carton damage or attachments missing in transit, please contact your dealer or our after sales service department.

Attachment: 1. Light: 1pcs 2. User Guide: 1pcs 3. Power cable: 1pcs

NOTICE

- 2, Do not turn on and off the unit frequently.
- 3, Make sure the power supply connects ground before using.
- 4, This unit is applicable for only indoor use and must be avoided water, moisture and shade damage. Working temperature should be 18~30°C.
- 5, Do not use it successively over 4 hours, otherwise it will shorten its lifetime.
- 6, Use cleaning tissue to remove dust on the external lenses periodically to optimize light output.
- 7, Do not remove or break the warranty label, otherwise it void warranty.
- 8, Always replace with the exact same type fuse, replacement with anything other than the specified fuse can cause fire or electric shock and damage your unit, and will overstep our manufacturer's warranty.

TECHNICAL SPECIFICATION

- 1, Voltage: AC110V, 50HZ/60HZ,
- 2, Power: 30W
- 3, Working Modes: Sound Active, Auto, Master-Slave
- 4, Light Source: (R:28 G:28 B:28)

Address setting:

	ON	OFF	FUNCTION
	10	1.2.3.4.5.6.7.8.9	DMX
	1.2.3.4.5.6.7.8.9	10	auto
	1.2.3.4.5.6.7.8	9.10	All light
	9	1.2.3.4.5.6.7.8.10	Strobe

CHANNELS:

Channel	Channel value	Function
CH1	1-255	On light(strobe)
CH2	1-255	Red
CH3	1-255	Green
CH4	1-255	Blue

Note

This product in the factory works good, packing integrity. All users should strictly abide by the above statement warnings and operating instructions, any damage caused by misuse, the company does not guarantee. Ignore manuals caused fault and problem also is not responsible for the dealer.

