

ROUBLESHOOTING

1. If the power supply indicator doesn't light up and the light doesn't work, please check the power supply and the input voltage.
2. In Stand-Alone operation, if the power supply indicator is alight but sound active indicator doesn't light up. So the laser will be shutted off.
 - A. Because sound is too low, please increase volume or turn up or adjust sensitivity knob.
 - B. If unit has been set up in slave mode, set up in master mode.
 - C. Make sure to have a good connection.
 - D. If the unit is failed, please turn off it, then turn on again after in 5 minutes. You still have a problem after trying the above solution, please contact your dealer or our company of service.

Warning


Please don't use eyes to see light directly.

In any installation and maintenance work, please confirm the power already cut off.

Note

This product in the factory works good, packing integrity. All users should strictly abide by the above statement warnings and operating instructions, any damage caused by misuse, the company does not guarantee. Ignore manuals caused fault and problem also is not responsible for the dealer.

Big four colors light



User Guide

UNPACKING INSTRUCTION

Unpacking:

Thanks you for purchasing this product. Please read user guide for safety and operations information before using the product. Keep this manual for future reference. Please check the attachments listed on the page after opening carton box. In the event of carton damage of attachments missing in transit, please contact your dealer or our after sales service department.

Attachment: 1. Light: 1pcs 2. User Guide: 1pcs 3. Power cable: 1pcs

NOTICE

- Do not turn on and off the unit frequently.
- Makes sure the power supply connects ground before using.
- This unit is applicable for only indoor use and must be avoided water, moisture and shade damage. Working temperature should be 18~30°C.
- Do not use it successively over 4 hours, otherwise it will shorten its lifetime.
- Use cleaning tissue to remove dust on the external lenses periodically to optimize light output.
- Do not remove or break the warranty label, otherwise it void warranty.
- Always replace with the exact same type fuse, replacement with anything other than the specified fuse can cause fire or electric shock and damage your unit, and will overstep our manufacture's warranty.

TECHNICAL SPECIFICATION

- Voltage: AC220V, 50HZ/60HZ,
- Power: 2200W
- Function: single light speed adjustable, can be controlled by controller
- Size: 535*450*240mm
- Weight: 8.34kg

AUTO

Auto cycles the built in programs without being controlled externally. It has no laser OFF.

OPERATION INSTRUCTION:

Stand-Alone Operation (Sound Active, AUTO mode)

The mode allows a single unit to react to the beat of the music in master mode.

- Install the units in a suitable position (laying or appending).
- Set dipswitch to select Sound Active or AUTO mode.
- Turn on the unit power, the unit begins rest, then the unit begins working.
- The unit will react to the low frequencies of music via the internal microphone. Adjust the audio sensitivity knob on the back of the unit to make the unit to be more or less sensitive in sound activate.

Address code setting

0=OFF 1=ON

DIPSWITCH CHART										FUNCTION	
#1	#2	#3	#4	#5	#6	#7	#8	#9	#10		
0	0	0	0	0	0	0	1	1	0	SOUND	
0	0	0	0	0	0	0	0	0	0	Control box	
DMX ADDRESS SETTING										0	DMX

Channel setting:

channel	Channel value	function
Ch1	1-255	Red
Ch2	1-255	Yellow
Ch3	1-255	Green
Ch4	1-255	Blue
Ch5	1-255	Change colors
Ch6	1-255	Change colors speed