



Multiple Color Changing LED Light

REV 04

User Manual

Professional LED

Thank you for purchasing this device. For the sake of safety and regular operation of this product, please read this manual carefully before using and operating it.

Display Screen:



Step 1: Press (MENU), back to previous page. You can choose the MENU at the first level menu.

Step 2: Press (UP) or (DOWN) to change the settings.

Step 3: Press (FUNC) to enter into next menu.

Remarks: The display screen will be disappear if you don't press the buttons about 15 seconds.

When you press any of the botton the display screen will retore to the original condition again.

Then loosen the botton, the system will autosave. The function of the first radix point of led display is for idicaing whether the DMX signal works or not.

Display Details:

Addr	A001—A512	DMX51 Address
Auto	pr-00----pr-09	Automatic
Spee	S001---S255	Sound Control Speed
Soun	So-00—S09	Sound Effects

DMX Instruction:

Ch1	0—63	Seven colors Mode
	64—127	Automatic Mode
	128---191	Sound Control Mode
	192—255	All the color bright
Ch2	0---255	Effect Mode
Ch3	0---255	Speed

Specifications:

Voltage: AC 220V/50Hz

Power Consumption: 35W

Lighting Source: 256 LED (R, G, B, W)

Control Mode: DMX512, Music Control, Automatic, Master-slave

Control Channel:6CH

Working Environment: Indoor use

Measurement: 31*23*22cm