LASER SHOW SYSTEM

F-08 LASER LIGHT USER MANUAL



GOBO LASER LIGHT USER MANUAL

Thank you for purchasing F-08 Gobos laser light.

Specification:

Voltage:110-120V/220-240V 50/60Hz Power:10W Scan system: Single-Chip

Scanning instrument: N1.8 high-precision STEP motor

Control mode:sound control,automatic,DMX512

Laser module: DPPS Cooling system:air cooled

Operating temperature:indoor 20 ℃-40 ℃

Product size:300x260x170mm Carton size:545x320x570mm

N.W:2KG G.W: 2.5KG

Install Instruction

make sure that light is locked-in, should make enough safety precautions. 2. Make sure the voltage and frequency is adapt to the power supply,

1. This light can install in any location, and the distance between the

light and people or others should be more then 1m, also please

and connect the light in the right way, then turn it on.

3. The connection of DMX512

The singal of the DMX512 controller is inserted by the 3 pins XLR socket of "input" and "output" of the light.

DIP switch DIP10+DIP9 ON: Automatic running (master light)

DIP10 ON:Sound control (master light)

When the master light is sound mode or automatic mode, the DIP1-DIP8

Other:

0:line+spot

1:line

DIP10 OFF: DMX mode/slave mode

CH1

DMX Channel

CH₂

CH₃

sound control; 150~255:automatic mode DMX mode

0:all are line; 255:all are spot; other:spot+line

DMX manual mode 0:stop; 1~49:clockwise; 50~99:anticlockwise; 100~255: direction automatically change

Function

0~49:no light; 50~99:DMX manual; 100~149:

Control spedd of rotation Length of line

CH4 0:no strobe; 1~255:strobe CH5

0~49:red+green; 50~99:red; 100~149:green; CH₆ 150~255: color automatically change

Maintain

Please make sure that the power supply is disconnection if you want to open or maintain the light. Keep the light dry and clean. It will be keep the light bright if you often clean the light, also can extend the life. So please

use the professional glass cleaning liquid when cleansing it. Don't use the alcohol or chemical liquid to cleanse it, and please cleanse inside of the light by vacuum cleaner at least one time every year.

Warning

Please be careful to operate when you install it.

Please don't use this product near water or other liquids.

Please don't install the light in high temperature environment.

The distance between the light and other objects should be at least 0.5m.

Please don't look at the beam of light directly, or it will be hurt your eyes.

To confirm the power supply have cut off before you open and repair the light.