# Single-greenanimation laser light



# USER'S MANUAL

Refore use the light, please read the manual.



Thank you for using the laser performer. For the sake of safety and better operation of this projector, please read this manual carefully before use and operate the projector, lest incur any personal injury or damage to the projector.

\*\* - Marc 1986-by Common (1997年 1998年 - Species 製作機 Species Species (1998年 - 1998年 - 1998年 - 1998年 - 1998年 - 1

PERSONAL MERCHANICAL PROPERTY AND ADMINISTRATION OF THE PERSON OF THE PE

<ul> <li>Package li</li> </ul>	st:
--------------------------------	-----

#### Product Introduction:

The projector adopts the latest appearance design to make it compact and light. The housing use imported paint.

🤼 - جامع etigeta, et same et estados (2 rigis \$12 rigis). Se estados en estados en estados en el Proposição de en en estados en entre en

The scanning system is vibratory mirror(15kpps-25kpps), DMX-512 signal 22 channels, international standard DMX-512 signal control or ILDA signal control.

Control modes: DMX-512 signal control , music control ,automatic, master and slave, ILDA.

The laser projector was applied for the place of public entertainment such as disco, night club and theater etc.

#### Function Introduction:

Laser module is semiconductor generator, laser wavelength are 532nm/green and 650nm/red, the two different laser module are combined to give off the yellow laser light. The laser light source has a long life span and highly stability, complying with the international standard.

Cip and twin there up sent down

Signer for <u>milet</u>t in a<sub>ll</sub>ebe.

#### Instructions

After unpacking, check whether the projector has been damaged by transport such as any screw loosening, reflecting mirror broken, etc. If everything is OK, select a proper location, hang the projector and adjust its angle properly, then connect the power cord and the ground wire before switch on at the means. Notice that while using this projector the green and yellow wire has to connect the ground properly by professions in Disconnect at the electrics and voltage before power on it. We suggest outstomer apply 220V or a transformer. 20 seconds after powered on the projector, it will self-check and then can be used.

Because of the radiate laser generator 's own characteristic, please terminate it for 10 minutes after using it for 30 minutes to secure the laser 's long life span

Avoid being interfered by other signals while using the DMX-512 signal controller.

# Technical Parameters: ad . repaiding and placego followers with the second

Rated voltage: AC220V ±10%

Rated frequency: 50HZ~60HZ

Power consumption: 50w

Laser power: 200mw

Laser source: solid semiconductor laser generator

Color: green/ 532nm

Scanning: 15kpps-25kppsmirror system

Channels: 12CH

Control mode: music control, DMX-512 signal control, automatic, master and slave or

ente produce la créga delle suit insprovitant mant millionime une may sicusif e

course operations of this projector, playing mead this magazal carretains

Accompany was of openings.

g , paga arii suen 🕟 🕬 🕬

ILDA signal control.

Cool system: fan

Operating environment: indoor Bandria modes. (JMD: 512 signal conego), en por control policinolog, matem. Per co., c

#### Channel 's function:

The GREEN laser light adopts international standard DMX-512 signal, and there are 12 channels, details as below:

named to each set of the Co

page of the first of the page of the page.

Committee of the Commit

Location Co. Co. Co., visite 400 (Co.)

en in grapher to the process of belowed the

	Descriptions	A Paris of Aphodyspace
CH1	Auto sound control and	energy and the audit page of the Levin and
CH2	turn off the lights	softgas <b>ignal manafilis</b> perhasi ist i zna site.
CH3	Choose the patterns	and great to fight different longer to our wife
CH4	Zip and roll from left to right	- Aministrative of graduation
CH5	Zip and roll from up and down	
CH6	Move from left to right.	
CH7	Move from up and down	
CH8	patterns rotation	and the figure of the last of
СН9	angle and speed of the rotation	PATE Autombs (249)
CH10	Zip and roll from big to small	ATA (60 CO) 100 SC -
CH11	Node sharpen and the saker and	modification to
CH12	strobe	· -;

# ● Signal Connection and Address Code Dialing: at the notice was a set of beautiful.

This GREEN laser performance system has controlled by on/off switch address code.

1 to 9 are the numerical value of DMX 512 signal switch,10 is the exchange switch of DMX512 signal control and music control, automatic, master and slave.

Control mode set up detail as bellow:

MODE		Control switch (ON)	
1	DMX-512	1-10set address, 2.3.4.5.6.7.8 is off	
2	Sound Controlled mode and master projector	1.2.3.4.5.6.7.8.910 is ON,	
3	Automatic Control mode and master projector	1 is ON	
4	Slave projector synchronization control mode	All are off and connected by DMX	

Under sound active control mode: There is a sound sensitivity adjustment function, so you can adjust it to the optimum sound according to your requirement.

### Operation of double -patterns controlling under DMX-512 control mode.

- 1. Under DMX-512 control mode (10:on), CH1: 84~125 is for pattern A controlling CH1:126~167 is for pattern B controlling.
- 2. CH2 is for patterns selection. CH3 is for controlling mode selection., CH4: 0~127 is for moving speed adjustment of double patterns (from slow to fast). CH4:128~255 is for moving speed adjustment of single pattern (from slow to fast), can be realized changed from double patterns into single pattern, patter A or pattern B).
- CH5 is for color control mode selection. CH6 is for color changing speed adjustment (from fast to slow).

in his mary training group of the complete daily water some of the

الكائم والإرادان

ndi gaga ya mahagan wasa e s

#### ILDA signal control mode:

When connected to ILDA signal, the switch will automatically turn to ILDA signal control mode.

Attention: Power off before the connection of ILDA signal to avoid the damage of the projector.


## Attention of Master/Slave Control Mode:

- 1. You can not connect to the DMX-512 controller when the master and slave projector are operating synchronously, otherwise the master and slave synchronous functions can't be realized,
- When operating the master and slave controlling, it must be only one master projector, otherwise it can not be operated synchronously.

# Master and Slave connection as bellow: 10 about anythold have additioned a language of



#### Pull Don't connect controller 01, regard (ALC) 2 2 3 AURD to make the consenum and the till 1 4



#### Safety marks:







A00日本15 人名

- ! Please make sure to switch off the power before installation or maintenance.
- ! Please keep the fan expedite and environment ventilated.
- ! This laser projector is designed for the indoor, so while using, please avoid any dripping. If you want to use for outdoor, please do enough waterproof measure.
- ! Before maintenances, please refer to eligible personnel
- ! Do not use any power voltage and light type of different specifications
- ! Please do not see the laser light directly, in case it might damage the eyes.
- ! Avoid electric shock! Bulb overheating.
- ! Do not use it frequently under the humid atmosphere.

#### Maintenance:

It is very important to keep the laser light clean, therefore please clean reflector lens monthly to keep the lights away from dust, dirt or fog juice. We suggest that clean the light with professional glass cleaning lotion and downy cloth. Keep the light clean regularly will not only maintain the maximum laser output brightness but also will extend the life span of the laser.

genannsteinige beläterig ein nicht eine Steinen der